



## **OB-X OUTBOARD CROSSOVER**

NB. The loudspeaker should never be connected directly to an amplifier without its external crossover box, to do so risks serious damage to the equipment.

## INSTRUCTIONS FOR BI-WIRING THE R80 LOUDSPEAKERS

The OB-X version of the R80 loudspeaker has been designed for optimum performance in a fully bi-wired configuration.

Please observe the guidelines carefully for correct configuration.

The speaker may optionally be wired with a single run of cable from amplifier to crossover when used in conjunction with high quality shorting cables at the crossover inputs.

+ Red shorted to Red. – Black shorted to Black.